

## Release Notes - Default Password Information

---

### IMPORTANT INFORMATION

Since Software Issue v4.2(003), the default Usernames and Passwords have been changed.

<b>Webpage Configuration</b> :	Username = dm	password = web
<b>Video FTP</b> :	Username = dm	password = ftp
<b>FTP Admin</b> :	Username = dmftp	password = ftp
<b>Telnet</b> :	Username = dm	password = telnet
<b>Serial</b> :	Username = dmconsole1	No password as default

These default usernames and passwords should be changed as soon as practical to maintain security. Always make a note of the new passwords, as these cannot be reset easily. A unit will have to be returned to the manufacturer to have a password reset.